
Operation Manual

Whirlpool Turm zu Schloss Schedling

Restricted, older and/ or disabled persons should take special care when using the whirlpool tubs. Infants should not be allowed to use whirlpools without supervision.



- 1 Hydromassage on/ off
- 2 Air massage on/ off
- 3 Massage jet weaker
- 4 Massage jet stronger
- 3+4 Interval function/ start cleaning

Commissioning

Let in warm bath water. The water level should be about 5-10 cm above the edge of the topmost nozzle.

Attention: The tub has a dry run protection. This will only release the system when this water level has been reached. If the tub does not work, please let some water in the tub until this level is reached.

The water cycle

By pressing the button, you can switch on the water circuit of your Easy Combi System. At the back and foot nozzles, as well as the side jets, a massage jet emerges from a water/ air mixture. This water jet has a preset intensity of approx. 60%. By pressing the - or + button, the intensity can be reduced or increased. Pressing the button again will knock the water massage off again.

The air circulation

Press the button to switch on the floor nozzles. Preheated air in the form of a massage jet exits at the nozzles. The massage jet has a preset intensity of 60%. By pressing the - or + button, the intensity can be reduced or increased. Pressing the button again switches the floor nozzles off again.

The interval function

Both cycles of the combi system have an interval function. These are started with the respective system switched on by pressing the - and + button simultaneously. The massage jet now oscillates sinusoidally up and down.

Press the two buttons again to return to normal operation. If you switch off the respective circular louse and switch it on again, the massage jet will start again in normal operation.

A few minutes after the water has drained after bathing, an automatic dry-blowing starts. This turns off by itself again.